



Figure 1: Monitoring Wells Used in Boundary Evaluation

0 500 1,000 Feet

Alluvial TI Zone Boundary Evaluation  
Butte Priority Soils Operable Unit

